

Model: VT904

4G QUAD BAND GPS VEHICLE TRACKER

Dual Passwords for Double Data Protection & Security

QUICK 'ACTIVATION WIZARD' & USER GUIDE



Included;

- 1 x GPS tracker – model: VT904 (input 12v~24v)
- 1 x wiring harness
- Free full user manual download from our websites
- Free mobile phone/tablet tracking APP (Android and Apple IOS)
- Free tracking website with 6 months history



This product requires a mobile SIM card (not included).
Data only SIM cards are not compatible.

A full owners operator manual can be downloaded from;
www.mongoose.com.au or **www.mongoose.co.nz**

ACTIVATION & SET-UP 'WIZARD' (Installers – see page6)

DOWNLOAD THE MOBILE APP (see Notes, page 8)

Go to App Store for Apple IOS

Go to Play Store for Android



Search for :- **4G MONGOOSE GPS**

Note: For this tracker to function accurately, ensure your mobile phone GPS location services are switched on.



THE ACTIVATION & SET-UP WIZARD

The wizard must be completed to unlock all the tracker & APP features

Open the APP, the wizard guides you through the process.

- ID (serial number) of the tracker (on tracker & carton)
- Phone number of the SIM card used in the tracker
- Your mobile phone number ('master user') *
- Trackers SIM card 'APN' See next page *
- Choose your own unique 6-digit 'logon' password (default is 222444)

* With some input data, the wizard opens your mobile phones text messages displaying the text code being sent. Just press send. A reply text message will be received confirming the action.



DUAL PASSWORDS – Double Data Protection & Security

There are 2 separate unique programmable passwords.

Password 1: LOGON

The logon password is to allow entry to the mobile APP and online website. This password is chosen by you when completing the 'activation wizard'.

Default is **222444**

Password 2: TEXT COMMANDS

This password is for text commands sent from the APP or your mobile phone. This password is chosen by you by selecting 'text password' in the 'command list'.

Default is **123456**

NOTE:

To protect your location data, only reveal your logon details to trusted persons.

Here are some APN examples;


Australia		New Zealand	
Telstra	telstra.internet or telstra.wap	Vodafone	vodafone.net.nz
Vodafone	live.vodafone.com	Spark	internet
Optus	connect or yesinternet or connectme	2 Degrees	
Aldi	mdata.net.au	Kogan	live.vodafone.com
Boost	telstra.mms	The Warehouse	warehouse
Moose	yesinternet	Skinny	wapaccess.co.nz
AmaySim	internet	Slingshot	

Contact your SIM card provider if your provider is not listed above or to verify the correct APN.

THE LOGON SCREEN

When the activation wizard has been completed (unlocks all the trackers & APP features), the next time you open the APP this logon screen appears.

- For users of a single tracker, enter the trackers ID (serial number) and your password. (ID is found on the tracker and carton)
- For users of multiple trackers who have been issued a Mongoose GPS account, enter the account name and password.
- Tick the 'remember me' box for quick and easy future logons without having to enter tracker or account details.
- When you press 'LOGON', you will be taken to the 'real time' tracking map to show a vehicles current/last reported location. For account holders, the map will show a vehicle from the last logon.



Note: Keep logon details confidential to prevent unauthorized use and access.

MAIN MENU & TEXT COMMAND LIST

Real Time (Live Tracking)

Opens the map to show the current or last reported location. Keep the map open to see trackers live progress.

History

Replay on-screen today, yesterday or any 24 hour period travel history.

Text Commands

Select how you wish the tracker to operate

Messages

See what messages have been sent to you

Setup Wizard

Geo-Fence

'Account' User Menu

Set a permitted radius of travel from a defined spot. Multiple geo-fences can be set. Each time the vehicle exits or enters, a text is sent to you.

Tracker Info'

Details such as trackers SIM number, master users number, vehicle registration number etc.

Set APN

APN may need to be changed if you change SIM card provider.

Account User Info'

Details of your company and contacts.

'Account' menu also includes;

Home:- Takes you to the main menu

List :- Select a tracker to be viewed

Monitor:- View all your trackers at the same time

Message:- Text messages sent to you from tracker.



CONTROL COMMANDS AVAILABLE VIA THE MOBILE APP

Command	Function
Arm / Disarm	Turns text alerts on or off. When ON, text alerts are sent for car alarm trigger, ignition on, shock (vibration) sensor or parked position change.
Engine immobiliser	Prevents engine starting by interrupting the starter motor – do not connect to other circuits. (extra cost option – check with the installer of this product)
Get Location Data	Provides latitude/longitude as a text message – click on blue text to open your phones Google maps to show location
Tracking Frequency	Sets how often the tracker updates its location when moving. Default is every 15 seconds.
Time Zone	Set hours ahead of GMT your tracker is located. Adjust for daylight saving when applicable.
Vibration Sensitivity	Set vibration (shock) level 1~9. 1 is most sensitive. See full manual for explanation and on/off command
Speed Alert	Sets a max'permitted speed. Speeding sends a text alert
Move Alert	Sets a radius of permitted movement. Beyond this limit sends a text alert
Master User Number	The main users mobile phone number
Authorised Number	2 other permitted users
Text Command Password	Choose your own 6-digit number (default 123456). This does not change your logon password
Geo-Fence	A permitted radius of travel. Text alerts are sent when exiting or entering a geo-fenced area
Factory Reset	Resets settings to factory default

Commands are sent from the APP to the tracker as a password protected text messages from your mobile phone. The APP opens your phones text messages showing the text code being sent to the tracker..... Just press send.


ONLINE WEBSITE

Go to: www.mongoosegps4g.com

To logon to the website, select either IMEI (serial number) or USER NAME (Apply to Mongoose to setup an account). Use same logon details as the mobile APP.



WIRING DIAGRAM



SP904 SECURITY PACK OPTION

The VT904 can be easily upgraded to provide vehicle and personal security in addition to vehicle location and travel history.

The SP904 Security Pack includes;

- An engine starter immobiliser relay kit (For engine immobilisation via the APP)
- A vehicle's car alarm connection kit (Sends the SOS alert when car alarm sounds)
- An 'SOS' button (Sends the SOS alert to authorised mobile phones)
- Security Pack installation instructions


All controllable via the mobile APP or simple text messages.

INSTALLATION

- Choose a hidden but accessible mounting location that allows for the tracker to face towards the sky – SIM card side facing up.
- Ensure there is no metal above that could shield the tracker.
- Do not put the tracker close to other emission sources such as computers, parking system, alarms, Bluetooth units or other electronic equipment.
- Remove the top cover and follow instructions below.
- Plug in the loom and park outdoors to get good GPS reception.
- Verify mobile and GPS reception by looking at the built-in LED's for correct flash code.
- Secure the tracker in the chosen location.

SIM CARD INSTALLATION

- Connect the tracker to the vehicle
- Remove the 'snap-on' top cover of the tracker
- Slide and lift SIM card holder - Insert SIM card
- Close holder and slide forward to lock
- Turn on the trackers' battery back-up isolating switch
- Replace the plastic cover



BLUE & YELLOW LEDS

Unlit	Reception is off (No power or unit asleep)
Lit solid	Working normal
Flashing once every 3 sec's	Searching for reception (Yellow – Mobile) (Blue – GPS)
Red LED	Power connected and internal battery charging

NOTE: The trackers internal battery will not provide backup power unless the isolating switch is 'ON'. If the tracker is removed from the vehicle, for whatever reason, turn the switch 'OFF' to prevent full battery discharge and possible damage.

Please download the full owners' manual as it contains detailed operating instructions and explanations as well as a greater range of operation commands

www.mongoose.com.au or www.mongoose.co.nz

TESTING VIA THE MOBILE APP

Using the mobile APP, check for correct operation without using the wizard.

- o Download and open the APP on your mobile phone – page 2
- o Press 'SKIP' at the bottom of the 'wizard' screen to go to LOGON screen
- o Enter the trackers ID (serial number) and default 222444 password
- o Map shows the current location (tracker is a Green triangle – Blue is your phone)
- o If location is not correct, press 'MENU'
- o Select 'Set APN' and enter SIM cards APN – see page 3
- o Allow a few minutes and check location which should now be correct
- o Please ask tracker owner to download the APP and complete the Activation 'Wizard' detailed in this manual

OTHER 4G MONGOOSE GPS TRACKERS

LT604 - BATTERY POWERED

NO INSTALLATION – NO WIRING - ATTACHES WITH POWERFUL MAGNETS.



Wireless GPS trackers - Up to 6 months on one battery charge !

Now you can track almost anything such as your 2nd vehicle, caravan, trailer, boat, farm equipment, motorbike, jet-ski, in fact anything that cannot provide power to the tracker. Easily attaches with their built-in strong magnets. A single charge can last for months. Programme to report just once a day or anything up to every 10 seconds – your choice!

See our websites for more information.



Australia

Email: sales@mongoose.com.au

www.mongoose.com.au

New Zealand

Email: sales@mongoose.co.nz

www.mongoose.co.nz

GPS tracking website: www.mongoosegps4g.com

Mobile APP:- 4G MONGOOSE GPS